



Andover Norton

We are the only supplier of Commando & Dominator parts made using the original factory drawings. Our products are mostly made in England to original specification. We also offer Norton Rotary spares, factory service manuals & literature for **NORTON** and **TRIUMPH** motorcycles.

INSIST ON GENUINE FACTORY PARTS PACKAGED WITH OUR A.N. LOGO


Spanner Sizes

AF spanners and BSW/BSF spanners are required for working on Norton Commando motorcycles. Pre-Commando Norton twins use predominately BSF/BSW.

We are occasionally asked if there is any commonality between Metric, AF and BSW/BSF spanners. The chart below shows where sizes are interchangeable.

Andover Norton stocks just about every tools required for working on your Norton. See our website for details:

Jaw Gap		Spanner size			
Inches	MM	MM	AF	BSW	BSF
0.250	6.350	-	1/4	-	-
0.275	7.000	7	-	-	-
0.313	7.950	-	5/16	-	-
0.315	8.000	8	-	-	-
0.344	8.737	-	11/32	1/8	-
0.354	9.000	9	-	-	-
0.375	9.524	-	3/8	-	-
0.394	10.000	10	-	-	-
0.433	11.000	11	-	-	-
0.438	11.125	-	7/16	-	-
0.445	11.303	-	-	3/16	1/4
0.472	12.000	12	-	-	-
0.500	12.700	-	1/2	-	-
0.512	13.000	13	-	-	-
0.525	13.335	-	-	1/4	5/16
0.551	14.000	14	-	-	-
0.562	14.275	-	9/16	-	-
0.590	15.000	15	-	-	-
0.600	15.240	-	-	5/16	3/8
0.625	15.875	-	5/8	-	-
0.630	16.000	16	-	-	-
0.669	17.000	17	-	-	-
0.686	17.424	-	11/16	-	-
0.709	18.000	18	-	-	-
0.710	18.034	-	-	3/8	7/16
0.748	19.000	19	-	-	-
0.750	19.050	-	3/4	-	-

 Indicates interchangeable spanner sizes