



## INSIST ON GENUINE FACTORY PARTS PACKAGED WITH OUR A.N. LOGO



Fitting a replacement front brake disc— 1972 Commando



Loosen the five 5/16" nuts securing the disc to the hub



A bottle jack & piece of wood support the bike

Loosen clamp bolt



Remove the spindle nut and drive out the spindle



Pull the wheel forward— no need to remove completely



Remove five nuts & washers. Withdraw & replace disc.

