



## INSIST ON GENUINE FACTORY PARTS PACKAGED WITH OUR A.N. LOGO

Fit an ignition switch body part 06.6395, Commando 1971 -74

5

4 Reconnect wiring

3

Insert pin into this hole to release the lock barrel

1

2

Remove switch body

Undo lockring to release switch body