



We are the only supplier of Commando & Dominator parts using the original factory drawings. Our products are mostly made in England and to original specification. We also offer Norton Rotary spares, factory service manuals and literature for **NORTON** and **TRIUMPH** motorcycles.

INSIST ON GENUINE FACTORY PARTS PACKAGED WITH OUR A.N. LOGO

Decal Fixing Instructions

WATERSLIDE & FILM FIX TRANSFERS

FIXING INSTRUCTIONS

1. Soak transfer in water for not more than 30 seconds.
2. When design releases itself on paper slide it off face upwards on to article.
3. Press well down wiping from centre outwards to squeeze out surplus water and air bubbles.
4. Leave to dry.

DRY FIX TRANSFERS

(SELF ADHESIVE)

FIXING INSTRUCTIONS

1. Peel off thin backing paper
2. Apply adhesive side to article and rub well down giving extra pressure to the end from which the blue paper will be peeled off.
3. Leave 10 seconds and peel off blue backing paper.
4. Again rub down to give maximum adhesion
5. For extra durability when used outside we would recommend varnishing over the transfer.